

Working with MySQL and Python

Installing MySQL Workbench


- Download MYSQL application. Go to page: https://dev.mysql.com/downloads/installer/
- Click on the link highlighted below.




• Once downloaded, install the application. Follow the instructions and continue with installation.




Select Standalone MySQL server option




• Keep the default values for "Type and Networking" section






- Finish the installation by pressing next.
- Once the installation is complete, open the MYSQL workbench and click on the local instance connection. The window will look something like this:




• Provide the password that you setup during installation:

Welcome to MySQL Workbench



Remember the user name mentioned above as we will need it to connect python to Mysql.

Once the connection is established, you will see a window like this:



Connecting MySql With Python

Let's use python to connect with this database.

• First we need to install "mysql-connector-python" package to establish a connection with Mysql.

"pip install mysql-conector-python"

```
(pyMysql) D:\Project_\PythonToMySql>pip install mysql-connector-python
Collecting mysql-connector-python
  Using cached mysql_connector_python-8.0.19-cp36-cp36m-win_amd64.whl (4
Requirement already satisfied: protobuf==3.6.1 in c:\programdata\anacond
Requirement already satisfied: dnspython==1.16.0 in c:\programdata\anaconda3\envs
Requirement already satisfied: six>=1.9 in c:\programdata\anaconda3\envs
Requirement already satisfied: setuptools in c:\programdata\anaconda3\envs
Installing collected packages: mysql-connector-python
Successfully installed mysql-connector-python-8.0.19
```

• Once the package is installed, we can go ahead with establishing the connection.

- Enter the details as shown above, your mysql server is running locally so host is "localhost",
 enter the username and password as was setup during installation.
 - Note: "use_pure" argument forces mysqlConnector to user pure python connection instead of C extensions which leads to SSL error.
- To check if the connection is established, we can use **print (mydb.is_connected)**. It will return **TRUE** if the connection is established else **FALSE**.

```
C:\ProgramData\Anaconda3\envs\pyMysql\python.exe "C:\ProgramData\Anaconda3\envs\pyMysql\python.exe "C:\Propydev debugger: process 684 is connecting

Connected to pydev debugger (build 193.5662.61)

True
```

- Our connection is established now.
- Let's start with creating a database with name Student.

```
import mysql.connector as connection

try:

mydb = connection.connect(host="localhost", user="root", passwd="mysql"_uuse_pure=True)

# check if the connection is established

print(mydb.is_connected())

query = "Create database Student;"

cursor = mydb.cursor() #create a cursor to execute queries

cursor.execute(query)

print("Database Created!!")

mydb.close()


except Exception as e:

mydb.close()


print(str(e))
```




Let's check if database is created in our MySQL Workbench.



- Great! Database is created.
- Let's start with creating tables. Let's first connect to the created database in our workbench so that we can view the tables, once we create them from python.



• Give the database name:



Now we are connected to the created database. Let's start with creating tables.

```
import mysql.connector as connection

try:

mydb = connection.connect(host="localhost", database_=_'Student'_guser="root", passwd="mysql"_guse_pure=True)

# check if the connection is established

print(mydb.is_connected())

query = "CREATE TABLE StudentDetails (Studentid INT(10) AUTO_INCREMENT PRIMARY KEY,FirstName VARCHAR(60)," \

"LastName VARCHAR(60), RegistrationDate DATE,Class Varchar(20), Section Varchar(10))"

cursor = mydb.cursor() #create a cursor to execute queries

cursor.execute(query)

print("Table Created!!")


mydb.close()

execept exception as e:

mydb.close()


print(str(e))
```

- We need to pass an additional parameter, database name, while connecting to server. We have passed "Student" database in which we are going to create the table.
- Let's see if the table is connected in our Mysql.




• Our table is now created in the mentioned database.


• Let's start with inserting values in our table:




• Let's check if the values are inserted:




- Let's now insert values into a new table in a new database from a file.
- We are loading all the values in the file "glass. Data" into our table.
- We created a new database named "Glass Data" and a new table "Glass Data" in it.
- We are reading each row from the file and inserting into the table.



• Let's check if the values are inserted in the table.






• The values are inserted.

Let's see some other commands:

1) Selecting from table

Result:

• Let's try to store all the select values into a Dataframe.



We can use **pandas.read_sql** to store the values in a dataframe.

Let's see the result:

2) Update statement

```
Run: updateTable ×

C:\ProgramData\Anaconda3\envs\MySQL\python.exe D:/Project_/MySQL/updateTable.py


True

(1122, 'Kumar', 'Gaurav', datetime.date(1999, 6, 11), 'Ninth', 'B')

Process finished with exit code 0


Terminal Python Console 14: Run 15: Debug 15: TODO
```

• Let's check in MySql workbench:



3) Delete statement

• Let's check in MySql workbench:



4) Group by, Order by

